



GetyourStudio

Camera Quick Guide

Presets

- ✓ The camera comes with a remote control with which many settings can be adjusted.
- ✓ A preset is a collection of the pan, tilt, and zoom settings for the camera.
- ✓ By first pressing the 'set preset' button, followed by a number between 0 and 9, that number is assigned to the current camera settings
- ✓ Now press that number to immediately switch to the corresponding camera settings



Color/image

- ✓ Press the 'menu' button on the remote
- ✓ Within the menu, click on 'camera'
- ✓ Click on 'color'
- ✓ Here, you can adjust both the Red Green & Blue Green tuning and the saturation. We do not recommend manually adjusting the white balance
- ✓ Now click on the 'menu' button to go back to the 'camera' menu
- ✓ Click on 'image'
- ✓ Adjust settings like the brightness, contrast, and sharpness.



The 'menu' button

COLOR

→WB Mode	Auto
RG Tuning	0
BG Tuning	0
Saturation	100%
Hue	7
AWB Sensitivity	High

[↑ ↓]Select [← →]Change value
[Menu]Back

IMAGE

→Brightness	7
Contrast	9
Sharpness	8
Flip-H	OFF
Flip-V	OFF
B&W-Mode	Color
Gamma	Default
DZoom	OFF
DCI	Close
Low-Light Mode	OFF

[↑ ↓]Select [← →]Change value
[Menu]Back

Focus

- ✓ Press the 'menu' button on the remote
- ✓ Within the menu, click on 'camera'
- ✓ Click on 'focus'
- ✓ Click on 'AF-zone'
- ✓ Here, you can choose the prioritized area for focusing
- ✓ You can also manually focus by pressing the blue 'manual' button on the remote, followed by using the zoom - and + buttons. This is only recommended to professionals



MENU

Language English
→(Setup)
(Camera)
(P/T/Z)
(Video Format)
(Version)
(Restore Default)

[↑ ↓]Select [← →]Change value
[Menu]Back [Home]OK

FOCUS

Focus Mode Auto
→AF-Zone Center
AF-Sensitivity Low

[↑ ↓]Select [← →]Change value
[Menu]Back