

GetyourStudio MINI

Quick Setup Guide



Introduction

- ✓ The GetyourStudio MINI contains a (1) broadcast quality Datavideo camera with optical zoom, (2) a dimmable LED ring, (3) a tripod, (4) a studio quality lavalier microphone, and (5) the Cube
- ✓ The Cube is the heart of the set: the camera and microphone are both connected to it, after which the cube itself is connected to a computer
- ✓ Most of the time the cube gets enough power from the computer's USB port. The AC-adapter should be used whenever this is not the case







- ✓ Turn on the LED ring by moving the switch to 'cable' on the left side of the back
- ✓ Adjust the brightness and color temperature with the turning knob on the right
- ✓ Navigate through the options the turning the knob left and right, select an option by pressing it







- ✓ The camera comes with a remote control with which many settings can be adjusted.
- ✓ A preset is a collection of the pan, tilt, and zoom settings for the camera.
- ✓ By first pressing the 'set preset' button, followed by a number between 0 and 9, that number is assigned to the current camera settings
- ✓ Now press that number to immediately switch to the corresponding camera settings







- ✓ Press the 'menu' button on the remote
- ✓ Within the menu, click on 'camera'
- Click on 'color'
- ✓ Here, you can adjust both the Red Green & Blue Green tuning and the saturation. We do not recommend manually adjusting the white balance
- ✓ Now click on the 'menu' button to go back to the 'camera' menu
- Click on 'image'
- Adjust settings like the brightness, contrast, and sharpness.



The 'menu' button

COLOR	
→WB Mode RG Tuning BG Tuning Saturation Hue AWB Sensitivity	Auto 0 0 100% 7 High
[↑↓]Select [←→]Change value [Menu]Back	







- Press the 'menu' button on the remote
- ✓ Within the menu, click on 'camera'
- Click on 'focus'
- Click on 'AF-zone'
- Here, you can choose the prioritized area for focusing
- ✓ You can also manually focus by pressing the blue 'manual' button on the remote, followed by using the zoom
 and + buttons. This is only recommended to professionals



The 'manual' button



